

SX302 TREMSmooth MT

MOISTURE TOLERANT LATEX UNDERLAYMENT

In some case it may be necessary to use a primer, such as where a subfloor is particularly absorbent. Priming of the subfloor will also reduce pinholing in the smoothing compound finish. When applying SX302 TREMSmooth MT to a Tremco surface dpm, apply either Tremco CS100 Epoxy Primer or CS190 Gritty Primer according to the data sheets.

Moisture Level	Subfloor Type	Primer
>75%RH	Cementitious	Tremco CS175 Epoxy Primer
<75%RH	Cementitious	Tremco CS150 Epoxy Primer
		Tremco CS175 Epoxy Primer
		Tremco CS190 Epoxy Primer
<75%RH	Calcium Sulphate	Tremco CS175 Epoxy Primer
	Non-Porous Substrate ††	Tremco CS100 Epoxy Primer
		Tremco CS190 Epoxy Primer

Note! Priming is required when an underfloor heating system is incorporated in the subfloor.