



For other nations, jurisdictions and climates, please consult the local building regulations that apply for avoiding mould and condensation. (For example, typical requirements may be: Netherlands: 0.65; Switzerland: 0.75; Belgium: 0.7; Germany: 0.7; Finland: 0.87. French, German and other standards often do not indicate a single number for acceptable risk, but are dependent on circumstances.) 4.

- Calculations have been performed in accordance with:
  - EN ISO 10211 2007 (British Standards)
    - IP 1/06 & BR497 (BRE Press)
- and with reference to the following publications:

EN ISO 6946 (British Standards)

BR443 (BRE Press)