

Application Instructions

Nullifire SC900 Series - Hybrid Intumescent

Nullifire
Smart Protection

Specification

Before the application commences, the application contractor should have a copy and be familiar the coating specification to be applied.

The coating specification should be constructed to give the required level of protection against the correctly classified environments in both the construction and completed phases of the project.

The coating specification will generally consist of:

- A primer system at a dry film thickness (DFT) dependent on the environmental conditions, corrosion and lifetime expectations. **The primer system shall not exceed 150 microns DFT total, with an absolute maximum allowable in overlap areas of 200 microns DFT. Overlap areas are not on flat surfaces, but limited to corners, connections and attachments, and shall not extend into the adjacent area by more than 100mm.**
 - An intumescent base coat at a DFT dependent on the individual steel structure to be protected, derived in accordance with the Product Loading Tables.
 - A topcoat system at a DFT dependent on the environmental conditions, aesthetic and lifetime expectations.
- Only primers and topcoats that are specifically approved by Nullifire are suitable for use with Nullifire Intumescent coatings.

Application Site Conditions

On-site application is the general term given to projects where the application of the intumescent coating takes place during the site construction of the building. As well as environments in accordance with ISO12944-2 (i.e. C1, C2, C3, etc.), this may be internal, semi-exposed or exposed dependent on the stage, size and phasing of construction. This must be understood in order to provide a suitable specification, and should consider the most severe environment, even if for only a short amount of time. Due to environmental considerations, water based coatings are commonly used, but solvent based coating and Hybrid systems may be used where increased environmental tolerance is required.

Off-site or in-shop application is the general term given to projects where the application of the intumescent coating takes place in a fabrication or coatings workshop in smaller pieces (such as modular or stick steel) before being transported to site for assembly. Solvent based coatings are generally used for this type of application due to the consistency of drying and less impact from climatic conditions, such as humidity or air movement.

Construction phase – weather resistance performance of the intumescent coating or scheme is given in terms of during the construction phase. This is in reference to the ability of the coating to resist the weather once through dry after achieving the final specified DFT. This is specifically in relation to light water flow (as from rainwater) moving over the surface of the coating without being allowed to accumulate.

Under no circumstances should condensation, ponding, pooling or standing water be allowed to build on the surface of the intumescent. Heavy running water and fresh concrete run-off must also be avoided. Methods to prevent this include, but are not limited to, shelters or physical manipulation of the substrate to prevent this.

Surface Preparation

1. New steel shall require the removal of all oil, dirt and grease.
2. Blast clean in dry atmospheric conditions using abrasive of suitable type and size, free from fines, moisture and oil, continue blasting until finish complies with BS EN8501:2007, preparation grade Sa 2½, with an average surface profile of 75 microns, and a minimum of 40 microns.
3. Surface profile measurements should be taken and recorded to ensure correct surface profile has been achieved.
4. Remove abrasive residues and all traces of moisture by blowing with clean, dry, oil free compressed air.
5. Apply the specified primer as soon as possible, and before any rust bloom appears or rust rashing occurs. This is recommended as within 4 hours of blasting. If this is not possible, or rust bloom or rust rashing appears, reblasting should take place.

Daily Records

Before, during and after application, record all environmental conditions, including but not limited to:

1. Air temperature
 2. Substrate temperature
 3. Relative humidity
 4. Dew point
 5. Paint temp
- This should be carried out minimum 4 times per application shift and recorded. Best practice would be to use automatic data loggers for continuous recording.

Application Method

Nullifire intumescent coatings are designed to suit airless spray application through electrical or pneumatic equipment. The best aesthetic finish will be achieved using such equipment, with specific guidelines given on the appropriate product Technical Data Sheets.

All equipment should be in good condition. Poor cleanliness and condition can lead to inefficient pump transfer leading to pressure losses affecting spray properties or meaning that higher than recommended and potentially unsafe pressures are needed.

Application by brush or roller is also possible for small areas, but will require more application coats to build to the same ultimate DFT as would be achieved by airless spray. The aesthetic finish achieved is also less than that achieved by airless spray.

Application Instructions

Nullifire SC900 Series - Hybrid Intumescent

Nullifire
Smart Protection

Primer

1. If all environmental conditions are within the manufacturers guidelines, application may proceed. If conditions are outside the guidelines, application must not proceed until conditions change.
2. Apply the primer to the specified DFT and inspect all freshly applied surfaces for missed areas/imperfections and carry out appropriate reinstatement measures.
3. When the primer has dried, conduct a dft survey to ensure the specified dft has been achieved and record all readings highlighting any low/high points. Areas of low DFT may need to be increased to meet the specification.
4. If the primer DFT is higher than the maximum allowable (i.e. 150 microns DFT), application of the intumescent should not proceed until corrected and within allowable tolerances. Rectification may include use of power tools to remove coating, or even complete re-blast. Any remediation carried out should still comply with the original specification outlined.

Intumescent

1. Remove all surface contamination (dirt,dust, oil, etc.) from the primed steel surfaces.
2. If the intumescent applicator/contractor is different from the primer applicator, they should ensure that the primer is applied to the correct specification and in line with the guidance above before proceeding.
3. The applicator should visually check for any areas on the primed steel surface that look high in gloss, and any such areas must be abraded/sanded to a matt finish in order to create a good anchor point (surface profile) before the intumescent is applied. Any residue should be removed before progressing, i.e. with clean, dry compressed air or a lint free cloth damped with solvent.
4. Inspect the primed steel sections for any signs of damage caused by erection and transport.
5. If damage is present, carry-out surface preparation and repair as per primer manufacturers guidelines. When all damage has been repaired and areas are clean, dry and free from contamination, application of the intumescent can proceed. **Caution: environmental conditions may change unexpectedly. SC900 series intumescent is designed to deliver shower resistance after a short period of drying. This is intended as short periods of light rain only, and not prolonged periods of heavy rain. All precautions must be taken to prevent the build up of ponding or standing water which may damage the coating and affect performance. Such precautions may include sheltering and position of the substrate to allow run-off.**
6. Consideration needs to be taken when conducting application if the relative humidity is higher than 85%. The higher atmospheric water content will cause the SC900 series intumescent to react faster. This will lead to a shortening of the working pot life. The applied coating will also dry faster.

7. It is recommended as best practice that a small test patch or area be prepared before commencing the full area to ensure that there are no issues with compatability, adhesion or drying, etc.
8. Onto the primed surface apply the intumescent and conduct Wet Film Thickness (WFT) checks to ensure correct thickness is achieved.
9. Any further coats can be applied after a 4 hour duration, or when the underlying coating is sufficiently dry, dependant on the local environmental conditions. Sufficiently dry can be assessed as the underlying coating is resistance to light pressure when touched.
10. 16-24hrs after the final coat has been applied, conduct a DFT survey to assess if the specified DFT has been achieved. If not, continue until the specified DFT is achieved to the agreed tolerances.
11. When the intumescent specified DFT is achieved, if a topcoat is required, it is recommended to follow the guidelines below:

Hybrid intumescent topcoat recommendation		
Intumescent DFT	<3 mm	24 hours
	>3 mm	48 hours

Thinning

Nullifire Intumescent are designed to be suitable for application without the need for thinning, as long as they are mechanically stirred until homogenous prior to application. However, should the need arise, it is permissible to add thinners to the SC900 series. The thinner type and maximum amount will be indicated on the relevant product Technical Data Sheet. However, the addition of thinners should only be done if absolutely necessary and may impact the ability of the coating to achieve the targeted WFT's. Excessive thinning may lead to longer drying times, potential solvent entrapment or soft coatings, and may lead to defects such as blisters sagging, runs. Any thinner with a water or alcohol content over 0.2% will cause the mixed intumescent reaction to speed up considerably, resulting in an unusable working potlife.

Topcoat

1. Once the intumescent has been applied to the specified DFT, it can be topcoated/topsealed in line with the drying recommendations above as long as the intumescent is 'thumb-nail' resistant.
2. Ensuring the intumescent coating surface is clean, dry and free from contamination, the topcoat may be applied in line with the specification, ensuring that the manufacturers technical guidance is followed.
3. Particular attention to the thickness and number of coats given in the specification. For higher classified environments (i.e. C3,C4,C5), it may be recommended to apply 2 x 75 micron DFT layers of the same topcoat. This is technically preferred to a single layer of 150 microns, as it is unlikely to have the same defects such as pinholes, cissing or misses, as it is in a single layer.

Application Instructions

Nullifire SC900 Series - Hybrid Intumescent

Nullifire
Smart Protection

4. It is recommended as best practice that a small test patch or area be prepared before commencing the full area to ensure that there are no issues with compatibility, adhesion or drying, etc. Issues could be encountered from many factors such as changes in formulations since approval was given, unnoticed contamination, etc.

Damage Repair

The procedure for damage repair will depend on the extent of the damage. For large areas, such as full structural elements, it may require return to the original application process.

For smaller areas, the following procedure may be used:

Topcoat only damage:

1. Remove all loose or unsound coating to a firm edge and chamfer the edges using abrasive paper.
2. All surfaces should be clean, dry and free from contamination.
3. The original topcoat should be reinstated in compliance with the original specification.

Intumescent (and topcoat) only - primer is intact:

1. Remove all loose or unsound coating to a firm edge and chamfer the edges using a sharp knife, making sure not to damage the primer, or abrasive paper.
2. The primer surface must be lightly abraded.
3. All surfaces should be clean, dry and free from contamination.
4. The original specification should be reinstated in compliance with the recommended DFT's and overcoating windows.

Damage to substrate – primer is damaged:

1. Remove all loose or unsound coating to a firm edge and chamfer the edges using a sharp knife.
2. Any and all corrosion products must be removed.
3. Prepare the substrate to an appropriate level, ensuring that the surface is not polished if hand tools are used.
4. For C1-C2 the SC900 can be applied to the freshly prepared steel. Agreement from the responsible project owner should be sought if this deviates from the original specification.
5. For C3, C4, C5 you must reinstate the primer to the original specification ensuring that there is no overcoating of any adjacent intact intumescent coating.
6. Continue to reinstate the original specification in compliance with the recommended DFT's and overcoating windows.

Equipment

1. If spray application has to stop for more than 15 minutes, the spray equipment must be cleaned.
2. It is also recommended that the spray equipment is cleaned after the application of every 6-8 kits.
3. Both of these help to prevent damage to the application equipment from reacted intumescent in areas of low movement such as dead spots or cavitations.

4. At the end of use, care should be taken that the equipment is fully cleaned with no dirty solvent left in the equipment. Any dirty solvent with only a small amount of residual SC900 series intumescent may still react to a gel overnight.

Transport and Storage

1. Once the specification has been achieved, the protected steelwork may be stored internally, protected from weathering until transport is required.
2. If storage is to be external, the full coating system must be fully dried and cured.
3. Storage should be done in a way that minimises damage to the coating system. This can be achieved by the use of wooden batons between pieces rather than face to face contact, and storing on the flange tips to minimise the surface area of any potential damage.
4. Lifting should be done using lifting points, D shackles and lifting eyes wherever possible. Lifting chains should be avoided, and slings used preferentially.
5. Any damage sustained in storage or transport should be corrected as soon as possible, reinstating the original specification.

Galvanised Steel

1. If galvanised steel needs to be fire protected, intumescent coatings can be used.
2. The guidance given is for fresh or aged galvanised steel.
3. The surface preparation required is dependent on the environment and is applicable to all Nullifire intumescent systems.
4. For specifications for C1 to C3 Internal environments, the surface preparation recommended is application of a mordant wash or etch primer as per manufacturers recommendations, or a sweep blast to produce a surface profile of 40 microns minimum.
5. Where mordant wash or sweep blasting is used, the use of an approved primer is recommended at 25-50 microns. For etch primer, it depends on the specific product used - consult Nullifire.
6. For specifications of C3 External and higher environments, only a sweep blast is recommended to produce a surface profile of 40 microns minimum. A standard specification should then be installed as per Nullifire guidance.

Application Instructions

Nullifire SC900 Series - Hybrid Intumescent

Nullifire
Smart Protection

Technical Service

Tremco CPG UK Limited has a team of experienced Technical Sales Representatives who provide assistance in the selection and specification of products. For more detailed information, service and advice, please call Customer Services on 01942 251400.

Disclaimer

Tremco CPG UK Limited products are manufactured to rigid standards of quality. The remedies available for any product which has been applied (a) in accordance with Tremco CPG UK Limited written instructions and (b) in any application recommended by Tremco CPG UK Limited, but which is proved to be defective, are set out in the relevant warranty, a copy of which can be provided on request.

Please note the information in this document is intended for guidance only, and it is the responsibility of the Buyer to determine the suitability of the product for its own particular use. Tremco CPG UK Limited has no control over the quality or condition of substrate, or the many factors that can affect the use and application of the product, and as such Tremco CPG UK Limited accept no liability for any loss, injury or damages resulting from such factors. Variations in application conditions, procedures and steelwork environments can cause unsatisfactory results, therefore always refer to the application instructions or Nullifire Technical Services before use for guidance.

Tremco CPG UK Limited reserves the right to alter product specifications without prior notice, in line with Company policy of continuous development, improvement and any regulatory or legal compliance requirements.

The English language version of this document shall prevail over any other translated version.